

2011 Infiniti EX

Quick Reference Guide



INFINITI.



- 01** INSTRUMENT BRIGHTNESS CONTROL SWITCH*
- 02** TRIP COMPUTER SWITCHES*
- 03** LOW TIRE PRESSURE WARNING LIGHT
- 04** HEADLIGHT AND TURN SIGNAL CONTROL
- 05** WINDSHIELD WIPER / WASHER SWITCH
- 06** STEERING WHEEL SWITCHES FOR AUDIO / BLUETOOTH®
- 07** INTELLIGENT CRUISE CONTROL (FULL-SPEED RANGE) BUTTONS*
- 08** PUSH BUTTON IGNITION
- 09** WARNING SYSTEMS SWITCH*
- 10** INTELLIGENT BRAKE ASSIST (IBA) SWITCH*
- 11** DYNAMIC DRIVER ASSISTANCE SWITCH*
- 12** INTELLIGENT KEY PORT*
- 13** TILT/ TELESCOPIC STEERING WHEEL SWITCH*
- 14** HOOD RELEASE*
- 15** VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH*
- 16** CONTROL PANEL DISPLAY SCREEN*
- 17** AUDIO SYSTEM
- 18** AUTOMATIC CLIMATE CONTROLS
- 19** FRONT PASSENGER AIR BAG STATUS LIGHT*

*See your Owner's Manual for more information.

new system features

| | |
|--|---|
| Blind Spot Warning (BSW) System (if so equipped) | 2 |
|--|---|

essential information

| | |
|--|---|
| Loose Fuel Cap | 3 |
| Tire Pressure Monitoring System (TPMS) | 3 |

first drive features

| | |
|---|---|
| INFINITI Intelligent Key™ System | 4 |
| Seat Adjustments | 4 |
| Outside Mirror Control Switch | 4 |
| Starting/Stopping the Engine | 5 |
| Headlight Control Switch | 5 |
| Windshield Wiper Switch | 5 |
| Climate Controls | 6 |
| FM/AM/XM® Radio with CD/DVD Player (if so equipped) | 6 |
| Parking Brake | 7 |
| Liftgate Release | 7 |
| Fuel-Filler Door | 7 |

system guide

| | |
|---|---|
| Cruise Control | 8 |
| Bluetooth® Hands-free Phone System (if so equipped) | 8 |
| Navigation System (if so equipped) | 8 |
| DVD Entertainment System (if so equipped) | 9 |
| HomeLink® Universal Transceiver (if so equipped) | 9 |



- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the “**Safety — Seats, seat belts and supplemental restraint system (section 1)**” of your Owner’s Manual.



Additional information about your vehicle is also available in your Owner’s Manual, Navigation System Owner’s Manual and at www.InfinityUSA.com.


This easy-to-use Quick Reference Guide is intended to help you more fully appreciate some of the unique features and functions of your new vehicle. However, it is not intended to replace your Owner’s Manual. The Owner’s Manual contains more detailed information to help you better understand the important safety warnings, features, operation and maintenance of your vehicle. All information, specifications, photographs and illustrations in this publication are those in effect at the time of printing. INFINITI reserves the right to change specifications or design without notice and without obligation.

new system features

Blind Spot Warning (BSW) System (if so equipped)

- The control switch is located on the left side of the instrument panel.
- The system automatically turns on when the engine is started and the indicator light on the switch **01** illuminates.
- The indicator lights, located next to the outside mirrors **02**, will activate when the BSW system detects a vehicle in the detection zone.
- If the turn signal is activated in the direction of a detected vehicle, a chime sounds twice and the BSW indicator light will flash.
- To cancel the system, push the control switch and the warning systems ON indicator will turn off.


For more information, refer to the “**Instruments and controls (section 2)**” and the “**Starting and driving (section 5)**” of your Owner’s Manual.



Loose Fuel Cap

- A LOOSE FUEL CAP warning message will appear in the dot matrix liquid crystal display **01** when the fuel-filler cap is not tightened correctly.
- The warning message will disappear when the vehicle detects the fuel-filler cap is properly tightened and the reset button **02** is pressed.
- If the cap is not properly tightened the Malfunction Indicator Light SERVICE ENGINE SOON may illuminate.


For more information, refer to the “**Instruments and controls (section 2)**” and the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



Tire Pressure Monitoring System (TPMS)

- A CHECK TIRE PRESSURE warning message will appear in the dot matrix liquid crystal display **01** and the TPMS light will illuminate when one or more tires are low on pressure and air is needed.
- After tire pressures are adjusted, drive the vehicle at speeds above 16 MPH (25km/h) and the warning and indicator light will disappear.
- When the low tire pressure warning light flashes for approximately 1 minute and then remains on, the TPMS is not functioning properly. Have the system checked by an INFINITI dealer.
- Tire pressure rises and falls depending on the heat caused by the vehicle’s operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire, which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light to illuminate. If the warning light illuminates in low ambient temperature, check the tire pressure in all four tires.

For more information, refer to the “**Instruments and controls (section 2)**” and the “**Starting and driving (section 5)**” of your Owner’s Manual.



first drive features

INFINITI Intelligent Key™ System

The INFINITI Intelligent Key™ System allows you to lock or unlock your vehicle, open your liftgate and start the engine.

- To lock or unlock the driver's or front passenger's door, push the door handle request switch **01** once.
- Push the door handle request switch **01** within 60 seconds of unlocking the door and all other doors will unlock.

NOTE: It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.



Seat Adjustments

- Push the control switch **01** forward or backward to slide the seat forward or backward.
- Push the switch **02** forward or backward to adjust the angle of the seatback.

SEAT LIFTER

- To adjust the angle or height of the seat, push the front or rear end of the switch **01** up or down.

POWER LUMBAR SUPPORT (if so equipped)

- Push the front or back end of the switch **03** to adjust the seatback lumbar area.

For more information, refer to the "Safety — Seats, seat belts and supplemental restraint system (section 1)" of your Owner's Manual.



Outside Mirror Control Switch

- Turn the control switch right or left to select the right or left side mirror.
- Move the control switch up, down, right or left to adjust the mirror angle.

For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.



Starting/Stopping the Engine

- Depress the brake pedal.
- Press the ignition switch **START/STOP** button to start the engine.

NOTE: It is important to make sure the INFINITI Intelligent Key™ is with you (that is, in your pocket or purse).

TURNING THE ENGINE OFF

- Move the shift lever to the P (PARK) position and apply the parking brake.
- Press the ignition switch **START/STOP** button to turn the engine off.

EMERGENCY ENGINE SHUT OFF

To shut off the engine in an emergency situation while driving, perform one of the following procedures:

- Rapidly push the push button ignition switch 3 consecutive times, or
- Push and hold the push button ignition switch for more than 2 seconds.


For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.



Headlight Control Switch

- Turn the headlight control switch **01** to the $\Rightarrow \text{D} \text{C} \text{E}$ position to turn on the front parking, side marker, tail, license plate and instrument panel lights.
- Turn the switch **01** to the $\Rightarrow \text{D}$ position to turn on the headlights.

For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.



Windshield Wiper Switch

Move the lever to the following positions to operate the windshield wipers:


- 01** Intermittent (**INT**) – Operates the speed-sensing front wipers intermittently.
- 02** Low (**LO**) – Front wipers operate at a continuous low-speed.
- 03** High (**HI**) – Front wipers operate at a continuous high-speed.
- 04** Rear Wiper (**REAR**) – Twist the end of the lever to operate the first (**INT**) or second (**ON**) speed settings for the rear wiper.



For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.

first drive features

Climate Controls



01 AUTO BUTTON/TEMPERATURE CONTROL KNOB

Press the **AUTO** button to turn the system on and the fan speed, air flow distribution and temperature will be automatically maintained. Turn the driver's side temperature control knob left for cooler or right for warmer air.

02 FAN SPEED CONTROL BUTTONS

Press the fan speed control buttons to manually adjust the fan speed up or down .

03 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

Press the front defroster button to turn the system on or off.

04 REAR WINDOW AND OUTSIDE MIRROR DEFROSTER SWITCH

Push the rear window defroster switch to turn the system on or off.

For more information, refer to the “**Instruments and controls (section 2)**” and the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner's Manual.

FM/AM/XM[®]* Radio With CD / DVD Player (if so equipped)



01 ON-OFF VOLUME CONTROL KNOB

Press the **VOL** knob to turn the system on or off. Turn the knob right or left to increase or decrease the volume.

02 TUNE/FOLDER/AUDIO CONTROL KNOB

To manually tune the radio, turn the **TUNE/FOLDER/AUDIO** knob left or right.

*XM[®] Satellite Radio is only available on vehicles equipped with optional XM[®] satellite subscription service.

For more information, refer to the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner's Manual.

Parking Brake

- To apply, firmly depress the parking brake pedal **01**.



- To release, firmly press the foot brake **02**, then press the parking brake pedal **01** and the parking brake will release.

For more information, refer to the **"Starting and driving (section 5)"** of your Owner's Manual.



Liftgate Release

- Use one of the following methods to unlock the liftgate:
 - Press the UNLOCK button on the INFINITI Intelligent Key™ once to open driver's door. Press again within 60 seconds and all doors, including the liftgate will unlock.
 - Push the liftgate request switch **01** while carrying the Intelligent Key with you.
- Once unlocked, push the opener switch **02** and pull the opener handle to open the liftgate.

For more information, refer to the **"Pre-driving checks and adjustments (section 3)"** of your Owner's Manual.



Fuel-Filler Door

Unlock the fuel-filler door using one of the following operations, then push and release the left side of the door to open.

- Push the door handle request switch while carrying the INFINITI Intelligent Key™ with you.
- Press the UNLOCK button on the Intelligent Key.
- Push the power door lock switch to the UNLOCK position.

For more information, refer to the **"Pre-driving checks and adjustments (section 3)"** of your Owner's Manual.



system guide

Cruise Control

- The cruise control system enables you to set a constant cruising speed.
- The system will automatically maintain the set speed until you tap the brake pedal, accelerate, cancel or turn the system off.

For more information, refer to the **“Starting and driving (section 5)”** of your Owner’s Manual.



Bluetooth® Hands-free Phone System (if so equipped)

- With an overhead microphone and sound transmitted through the audio system speakers, the Bluetooth® Hands-free Phone System utilizes Bluetooth wireless technology and voice recognition to provide hands-free cellular phone communication.

For more information, refer to the **“Monitor, climate, audio, phone and voice recognition systems (section 4)”** of your Owner’s Manual or please visit www.InfinitiUSA.com/bluetooth.



Navigation System (if so equipped)



- Your Navigation System can calculate a route from the current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- The Navigation System will continually update your vehicle’s position. If you have deviated from the original route, it will recalculate the route from your current location.
- The Navigation System can also provide you with important data, such as; distance to empty, your tire rotation schedule and other maintenance interval reminders.

For more information, please refer to your Navigation System Owner’s Manual.

DVD Entertainment System (if so equipped)

- With this Entertainment System, you can play video files via a DVD or CD from the control panel.
- To view movies on the control panel, stop the vehicle in a safe location, move the shift lever to the P (PARK) position and apply the parking brake.
- To reduce driver distraction, movies will not be shown on the front display while the vehicle is in any drive position.

For more information, refer to the **"Monitor, climate, audio, phone and voice recognition systems (section 4)"** of your Owner's Manual.



HomeLink® Universal Transceiver (if so equipped)



- The HomeLink® system can learn and consolidate the functions of up to three different handheld transmitters, operating items such as; garage doors, property gates, outdoor and indoor lights or alarm systems.

For more information, refer to the **"Instruments and controls (section 2)"** of your Owner's Manual, the HomeLink® website at www.homelink.com or call 1-800-355-3515.



INFINITI.

All illustrations, photographs and specifications in this guide are based on the latest product information; some vehicle parts cannot be shown in certain photographs. Some vehicles are shown with optional equipment. See actual vehicles for complete accuracy. Infiniti Division of Nissan North America, Inc. reserves the right to make changes at any time, without notice, in prices, colors, materials, equipment, specifications and models, and to discontinue models or equipment. Availability and delivery time for particular models and equipment combinations may vary. For information on availability, additional options or accessories, contact your Infiniti dealer. All specifications, options and accessories shown in this guide apply to the 49 continental states. Specifications, options and accessories may differ in Hawaii, U.S. territories and other countries. INFINITI, the Infiniti logo and INFINITI model names are Nissan trademarks.