2010 Infiniti Service and Maintenance Guide



TABLE OF CONTENTS



OWNER'S LITERATURE INFORMATION2

INTRODUCTION

Infiniti Maintenance	3
Why Infiniti Service?	
Extended Service Products	5
Genuine Infiniti Collision Parts	6

SCHEDULED MAINTENANCE GUIDE

Determining the Proper Maintenance Interval
Explanation of Scheduled Maintenance Items
Maintenance Schedules
Maintenance Log

OWNER'S LITERATURE INFORMATION

INDEX OF TOPICS

WHERE TO FIND INFORMATION

Radio/CD/Heater/AC OperationOw	vner's Manual: chapter 4
Starting and Driving Your Vehicle	vner's Manual: chapter 5
Security System OperationOw	vner's Manual: chapter 2
Changing a Flat TireOw	vner's Manual: chapter 6
New Vehicle Limited WarrantyWa	arranty Information Booklet: page 4
Federal Emission Control WarrantiesWa	arranty Information Booklet: page 7
California Emission Control Warranties	arranty Information Booklet: page 10
Tire Pressure/RotationOw	vner's Manual: chapter 8
Tire Warranties/Safety InformationWa	arranty Information Booklet: pages 22 to 45
Consumer Affairs AssistanceWa	arranty Information Booklet: page 2
Cu	stomer Care/Lemon Law Information Booklet: page 5*
Do It Yourself InformationOw	vner's Manual: chapter 8
General MaintenanceOw	vner's Manual: chapter 8

2 * Not applicable outside of the United Sates.

INFINITI MAINTENANCE



Maintain Your Investment

Preventative scheduled maintenance is an important investment to optimize the performance, durability, reliability, safety and resale value of your Infiniti. Scheduling your vehicle's maintenance at the recommended intervals will ensure your vehicle is running at its best.

We want you to enjoy your Infiniti vehicle. This Service and Maintenance Guide is designed to help you make sure your vehicle receives proper and timely maintenance that is necessary. Key services are explained in detail, along with an outline of scheduled maintenance to help you maintain your vehicle. Your local Infiniti dealer can assist you in determining the best schedule based on your driving habits and local conditions.

Failure to perform scheduled maintenance may result in excluding portions of your vehicle from warranty coverage and may reduce the performance, durability, reliability, safety and/or resale value of your vehicle. See your Warranty Information Booklet and Owner's Manual for details.

WHY INFINITI SERVICE?*

To preserve the quality and safety of your vehicle, an authorized Infiniti dealer is recommended for maintenance or repair. Only an authorized Infiniti dealer offers you these advantages:

- Factory Trained and ASE certified technicians
- Immediate access to warranty service history and factory technical information
- Latest diagnostic, special tools and service techniques
- Genuine Infiniti Parts that meet Infiniti's demanding standards
- 12 month/12,000 mile parts and labor limited warranty when Genuine Infiniti Parts are installed by your dealer
- Complimentary Multi-Point Inspections (at participating dealers)
- Service Loan Car availability for scheduled warranty service.**
- Clear, up-front estimates
- Shuttle service/Courtesy van (at participating dealers)

We recommend relying on our trained Infiniti service specialists, who refer to their detailed knowledge of your Infiniti in every service they perform. Plus, they use Genuine Infiniti Parts, designed and engineered specifically to maintain your Infiniti's original integrity. That's the distinction of your authorized Infiniti dealer.

* May differ or not apply outside the United States, please inquire of your dealer.

**Available during Basic New Vehicle Limited Warranty at participating Infiniti dealers. Subject to availability. Restrictions apply.



Your Service – Your Way



Elite | Infiniti Extended Protection Plan*

Long Term Coverage

The Elite Infiniti Extended Protection Plan provides you with long term coverage to 7 years/100,000 miles. Coverage under the optional Elite Infiniti Extended Protection Plan and the Infiniti Limited Warranties begins with the delivery of the vehicle to the first retail buyer. Accordingly, your agreement may provide coverage for your vehicle for a portion of the same period as your New Vehicle Warranty. Upon expiration of the applicable Limited Warranties, the full spectrum of the Elite Infiniti Extended Protection Plan coverage is in force to the end of the time or mileage term. During the period of your Basic Warranty, the Elite Infiniti Extended Protection Plan provides you with Rental Car Coverage only.

New Vehicle Limited Warranty

Elite Infiniti Extended Protection Plan (7 years/100,000 miles) benefits include:

mechanical breakdown protection

Roadside Assistance extended

car rental coverage

* This product is not available outside the United States.

Benefits You Can Count On

SERVICE AT AUTHORIZED INFINITI DEALERSHIPS/REPAIR FACILITIES.

With the Elite Infiniti Extended Protection Plan, service is completed by Infiniti trained technicians.

UNLIMITED CLAIMS.

No limit on the number of claims for covered repairs.

PROVIDES FOR THE COST OF GENUINE ORIGINAL EQUIPMENT REPLACEMENT PARTS. Designed for use on Infiniti vehicles. No inferior substitutes.

EMERGENCY TOLL-FREE HELP.

If a breakdown occurs outside your area, you are covered. Just contact the nearest Infiniti dealer, or call the special toll-free number for assistance.

SUBSTITUTE TRANSPORTATION.

If a mechanical breakdown occurs and you require alternate transportation, Infiniti will reimburse you for actual expenses up to \$50 per day, to a maximum of 5 days, and \$250 per service visit.

TRANSFERABLE TO A NEW OWNER.

Should you sell your Infiniti before your coverage expires, you can transfer your Elite Infiniti Extended Protection Plan**, thereby enhancing resale value.

CONVENIENT AND ECONOMICAL. Coverage that costs only pennies per day. Your Infiniti dealer will be happy to include the cost in your monthly car payment.

** A nominal transfer fee may apply. For details please refer to the Elite Infiniti Extended Protection Plan Service Agreement or contact your Infiniti dealer.

GENUINE INFINITI COLLISION PARTS

If you have an accident, insist on Genuine Infiniti Collision Parts. If you want your vehicle to be restored using parts made to Infiniti's original exacting specifications – if you want it to last, help to protect your personal safety and to help hold its resale value, the solution is simple. Tell your insurance agent and your repair shop to use only Genuine Infiniti Collision Parts.

Many non-genuine parts are copies made from impressions of Infiniti parts and may not match the specifications and performance standards of Genuine Infiniti Parts. As a result, non-genuine parts may not look or fit right, and may be less safe.

The hood on your vehicle is a good example. Infiniti designed it with hood buckling creases to help prevent the hood from penetrating the interior of your vehicle in an accident. Non-genuine parts may not provide such built-in safeguards.

In some states, the law says you must be advised if non-genuine parts are used to repair your vehicle. **Why should you take a chance?**

Replacement Panel Limited Lifetime Corrosion Warranty*

See your participating Infiniti dealer for details.

If you have your collision damage repaired using Genuine Infiniti Outer Sheet Metal Panels you don't have to worry about corrosion. That's because these panels are warranted against inside out rust-through perforation for as long as you own your Infiniti. Another reason to insist on Genuine Infiniti Collision Repair Parts.

^{*} This warranty does not apply to vehicles or parts, not distributed by Nissan North America and/or sold outside the United States.

DETERMINING THE PROPER MAINTENANCE INTERVAL

As a condition of your vehicle's warranty, you are responsible for properly maintaining your vehicle. In maintaining your vehicle, you should follow either Schedule 1 or Schedule 2 as listed below. Use these guidelines to determine which maintenance schedule to use.

SCHEDULE 1 (more severe operating conditions), every 3,750 miles or 3 months, whichever comes first

Use Schedule 1 if you primarily operate your vehicle under any of these conditions:

- Repeated short trips of less than 5 miles in normal temperatures or less than 10 miles in freezing temperatures
- Stop-and-go traffic in hot weather or lowspeed driving for long distances
- Driving in dusty conditions or on rough, muddy, or salt-spread roads
- Towing a trailer, or using a camper or car-top carrier

SCHEDULE 2 (less severe operating conditions), every 7,500 miles or 6 months, whichever comes first

Schedule 2 features 7,500-mile service intervals; with Schedule 2 <u>fewer</u> maintenance items are regularly checked or replaced than with Schedule 1.

Generally, Schedule 2 applies only to highway driving in temperate conditions. Use Schedule 2 only if you primarily operate your vehicle under conditions other than those listed in Schedule 1.

PREMIUM MAINTENANCE*

Premium Maintenance is an Infinitirecommended optional upgrade that adds services to Schedule 1 and 2 when maintenance is performed.

Performing the Premium upgrade services may optimize the performance, durability, reliability, and resale value of your vehicle. (Premium Maintenance items are available at every 30,000 miles or 24 month interval.)

*Premium Maintenance is an Infiniti-recommended option; however, you need not perform such maintenance in order to maintain the warranties which come with your Infiniti. Premium Maintenance may not be available outside the United States, please inquire of your dealer.

EXPLANATION OF SCHEDULED MAINTENANCE ITEMS

The following descriptions are provided to give you a better understanding of the scheduled maintenance items that should be regularly checked or replaced. The maintenance log indicates at which mileage/time intervals each item requires service.

In addition to scheduled maintenance, your Infiniti requires that some items be checked during normal day-to-day operation. You can find these items listed under "General Maintenance" in Chapter 8 of your Owner's manual.

Items marked with **"*"** are recommended by Infiniti for reliable vehicle operation. You are not required to perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

When applicable, additional information can be found in the "Do-it-yourself" sec-

tion in Chapter 8 of your Owner's Manual.

NOTE: Nissan North America does not advocate the use of non-OEM approved aftermarket flushing systems and strongly advises against performing these services on a Infinti product. Many of the aftermarket flushing systems use non-OEM approved chemicals or solvents, the use of which has not been validated by Nissan North America.

For recommended fuel, lubricants, fluids, grease, and refrigerant refer to Chapter 9 in your Owner's Manual.

Emission Control System Maintenance:

Drive Belts*

Check engine drive belts for wear, fraying or cracking and for proper tension. Replace any damaged drive belts.

Engine Air Filter

Replace at specified intervals. When

driving for prolonged periods in dusty conditions, check/replace the filter more frequently.

Engine Coolant*

Drain and flush the cooling system at the specified interval.

Engine Oil and Oil Filter

Replace engine oil and oil filter at the specified intervals. For recommended oil grade and viscosity refer to Chapter 9 in your Owner's Manual.

Engine Valve Clearance*

Inspect only if valve noise increases. Adjust valve clearance if necessary.

Evaporative Emissions Control Vapor Lines*

Check vapor lines and connections for leaks or looseness. Tighten connections or replace parts as necessary.

EXPLANATION OF SCHEDULED MAINTENANCE ITEMS

Fuel Filter

Maintenance-free item (In-tank type filter).

Fuel Lines*

Check the fuel hoses, piping and connections for leaks, looseness, or deterioration. Tighten connections or replace parts as necessary.

Spark Plugs

Replace at specified intervals. Install new plugs of the same type as originally equipped.

Chassis and Body Maintenance:

Brake Lines and Cables

Visually inspect for proper installation. Check for chafing, cracks, deterioration, and signs of leaking. Replace any deteriorated or damaged parts immediately.

Brake Light and Cruise Control Switches

Inspect the clearance between the brake pedal and the switches.

Brake Calipers, Pads, Rotors

Check for wear, deterioration and fluid leaks. Replace any deteriorated or damaged parts immediately.

Climate Controlled Seat Filter

Replace at specified intervals (M45/M35/FX50/FX35/G37 Convertible, if so equipped).

Exhaust System

Visually inspect the exhaust pipes, muffler and hangers for leaks, cracks, deterioration, and damage. Tighten connections or replace parts as necessary.

In-Cabin Microfilter

Replace at specified intervals. When driving for prolonged periods in dusty conditions, replace the filter more frequently.

Propeller Shaft(s)

Check for damage, looseness, and grease leakage (4WD/AWD/RWD).

Steering Gear and Linkage, Axle and Suspension Parts, Drive Shaft Boots

Check for damage, looseness, and leakage of oil or grease. Under severe driving conditions, inspect more frequently.

Tire Rotation

Tires should be rotated every 7,500 miles according to the instructions in the Owner's Manual (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible). When rotating tires, check for damage and uneven wear. Replace if necessary.

Transmission Fluid – Automatic or Manual, Differential Oil, Transfer Case Oil

Visually inspect for signs of leakage at specified intervals. If towing a trailer, using a camper or car–top carrier, or driving on rough or muddy roads, replace the transmission fluid/oil at every 30,000 miles or 24 months (except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission). **9**

OFF-ROAD MAINTENANCE (QX56 ONLY)

Check the following items more frequently after driving off-road through deep sand, mud or water:

- Brake pads and rotors
- Brake lines and hoses
- Differential oil, transmission fluid, and transfer case oil
- Steering linkage
- Propeller shafts and drive shafts
- Engine air filter
- In-cabin microfilter

MAINTENANCE SCHEDULES



The following Maintenance Schedule has been compiled by Infiniti to assist you in performing the recommended maintenance services and keeping appropriate records of services performed. Along with the related repair invoices, receipts, and other such records, a properly documented maintenance history could enhance the value of your vehicle should you ever wish to sell it. The services listed represent the minimal factory recommended requirements for each time/mileage interval, up to 120,000 miles / 96 months.

Beginning on page 46 you will find a maintenance log that should be used to track when and where services were performed. Ask your Service Consultant to stamp and update your log each time your vehicle is serviced. For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer.

MPI's are performed by Infiniti factory trained Technicians who will provide you with a detailed report of your vehicles condition.

Driving your Infiniti should be as worry-free an experience as possible. Trust your Infiniti dealership to inspect and maintain your vehicle so you can take pride in knowing your vehicle is ready for the road ahead.

*Available at participating dealers

COMPLIMENTARY MULTI-POINT INSPECTION*

			<u>Multi-Poin</u>	nt Vehicle Inspection
Cus	tom	ier N	Name:Year/M	odel: Date:
Mile	eage	e:		Work Order #:
Ser	/ice	Сог	nsultant:	Technician:
CH	ECK	ED /	AND OKAY	CHECKED AND OKAY
	M	AY N	NEED FUTURE ATTENTION	MAY NEED FUTURE ATTENTION
		R	EQUIRES IMMEDIATE ATTENTION	REQUIRES IMMEDIATE ATTENTION
			INTERIOR / EXTERIOR	BATTERY PERFORMANCE
1	1	1	Head Lights / Tail Lights / Turn Signals / Brake Lights Hazard Warning Lights / Exterior Lamps	24 24 24 Battery Terminals / Cables / Mountings
2	2	2	Windshield Washer Spray / Wiper Blades	25 25 25 Check Condition of Battery (Storage Capacity Test)
3	3	3	Windshield Condition (Inspect for Cracks, Chips, or Fitting)	Pass Recharge Retest Fail Date Code
4	4	4	Upholstery / Carpet / Floor Mats / Mirrors / Glass	BRAKE Brake Inspection Not Performed This Visit
5	5	5	Emergency Brake Adjustment	26 26 26 Left Front Brake Lining mm
6	6	6	Hom Operation	26 26 26 Left Rear Brake Lining mm
7	7	7	Fuel Tank Cap Gasket	26 26 26 Right Front Brake Lining mm
8	8	8	In-Cabin Microfilter (if equipped)	26 26 26 Right Rear Brake Lining mm
9	9	9	Clutch Operation (if equipped)	TIRE
			UNDER VEHICLE	Left Front Right Front
10	10	10	Shock Absorbers / Suspension	27 27 27 Tire Tread32nds 27 27 27 Tire Tread32nds
11	11	11	Steering Gear Box / Linkage and Boots / Ball Joints / Dust Covers	27 27 27 Wear Pattern 27 27 Wear Pattern
12	12	12	Muffler / Exhaust Pipes / Mountings	27 27 27 Tire Pressurepsi 27 27 27 Tire Pressurepsi
13	13	13	Engine Oil and/or Fluid Leaks	Left Rear Right Rear
14	14	14	Brake Lines / Hoses / Parking Brake Cable	27 27 27 Tire Tread32nds 27 27 27 Tire Tread32nds
15	15	15	Drive Shaft Boots / Constant Velocity Boots / U-Joints / Transmission Linkage (if equipped)	27 27 27 Wear Pattern 27 27 Wear Pattern
16	16	16	Transmission / Differential / Transfer Case (Check Fluid Level, Fluid Condition and Fluid Leaks)	27 27 27 Tire Pressurepsi 27 27 27 Tire Pressurepsi
17	17	17	Fuel Lines and Connections / Fuel Tank Band / Fuel Tank Vapor Vent System Hoses	COMMENTS / ESTIMATES
			UNDER HOOD	
18	18	18	Fluid Levels: Oil / Coolant / Battery / Power Steering / Brake / Washer / Automatic Transmission	
19	19	19	Engine Air Filter	
20	20	20	Drive Belts (condition and adjustment)	
21	21	21	Engine Coolant System	
22	22	22	Cooling System Hoses / Heater Hoses / Air Conditioning Hoses and Connections	
		2.2	Radiator Core and Cap	

3,750 MILES OR 3 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 7,500 Miles or 6 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

3 ⋗ Z -Z ⋗ Z 0 S 0 Т C

7,500 MILES OR 6 MONTHS

SCHEDULE 1 MAINTENANCE

- □ Replace engine oil and filter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - ___ Drive shaft boots (4WD/AWD)
 - __ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)

Equipment varies by model. Perform only those operations that apply to your vehicle.

11,250 MILES OR 9 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter


SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 15,000 Miles or 12 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

15,000 MILES OR 12 MONTHS

SCHEDULE 1 MAINTENANCE



- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - ____ Automatic transmission fluid ²
 - ___ Axle & suspension parts
 - ___ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches 1
 - __ Differential oil
 - __ Drive shaft boots (4WD/AWD)
 - __ Exhaust system
 - ___ Front suspension ball joints
 - ___ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - __ Steering linkage ball joints
 - ____ Transfer case oil (4WD/AWD)

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- Replace in-cabin microfilter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - ___ Automatic transmission fluid ²
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
- ___ Brake light & cruise control switches ¹
- __ Differential oil
- ___ Drive shaft boots (4WD/AWD)
- ___ Manual transmission oil
- ___ Propeller shaft (4WD/AWD/RWD)
- ___ Transfer case oil (4WD/AWD)

E

3

⋗

Z

-

¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible). Equipment varies by model. Perform only those operations that apply to your vehicle.

² Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission. Equipment varies by model. Perform only those operations that apply to your vehicle.

18,750 MILES OR 15 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 22,500 Miles or 18 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

22,500 MILES OR 18 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and

G37 Convertible)

□ Inspect the following:

- _____Axle & suspension parts
- ___ Brake calipers, pads, rotors
- __ Drive shaft boots (4WD/AWD)
- __ Exhaust system
- ___ Front suspension ball joints
- ___ Propeller shaft (4WD/AWD/RWD)
- ___ Steering gear and linkage
- __ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Rotate tires (except G37 Sedan 2WD
- Sport, G37 Coupe 2WD Sport and G37 Convertible)

Equipment varies by model. Perform only those operations that apply to your vehicle.

26,250 MILES OR 21 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 30,000 Miles or 24 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

30.000 MILES OR 24 MONTHS

SCHEDULE 1 AND 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Replace climate controlled seat filter (M45/M35/FX50/FX35/ G37 Convertible, if so equipped)
- Replace engine air filter
- □ Replace in-cabin microfilter
- □ Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
- Automatic transmission fluid 1,3 ___ Front suspension ball joints Fuel lines/connections
- Axle & suspension parts
- Brake lines & cables
- Brake calipers, pads, rotors
- Brake light and cruise control switches²
- Differential oil¹
- Drive shaft boots (4WD/AWD)
- Exhaust system

Propeller shaft (4WD/AWD/RWD) Steering gear and linkage Steering linkage ball joints

Fuel tank vapor vent system hoses

- Manual transmission oil 1
- Transfer case oil (4WD/AWD)¹
- ¹ Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

PREMIUM MAINTENANCE

Premium Maintenance adds the following services to

- □ Replace engine drive belts Replace manual transmission oil
- Replace radiator cap

Replace differential oil

Lubricate all locks/hinges

Schedule 1 & 2:

□ Replace transfer case oil (4WD/AWD)

Replace automatic transmission fluid ³

- Replace wiper blades
- □ Inspect the following:
- All lights Headlights/adjust if necessary

21

33,750 MILES OR 27 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 37,500 Miles or 30 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

37,500 MILES OR 30 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and
 - G37 Convertible)
- □ Inspect the following:
 - ____Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - __ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

Replace engine oil and filter
 Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and

G37 Convertible)

Equipment varies by model. Perform only those operations that apply to your vehicle.

41,250 MILES OR 33 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 45,000 Miles or 36 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

45,000 MILES OR 36 MONTHS

SCHEDULE 1 MAINTENANCE

- □ Replace engine oil and filter
- Replace in-cabin microfilter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- Inspect the following:
 - ___ Automatic transmission fluid ²
 - ___ Axle & suspension parts
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches ¹
 - __ Differential oil
 - __ Drive shaft boots (4WD/AWD)
 - __ Exhaust system
 - ___ Front suspension ball joints
 - __ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - __ Steering gear and linkage
 - __ Steering linkage ball joints
 - ___ Transfer case oil (4WD/AWD)

SCHEDULE 2 MAINTENANCE

- Replace engine oil and filter
- Replace in-cabin microfilter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- Inspect the following:
 - ___ Automatic transmission fluid ²
 - ___ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches ¹
 - __ Differential oil
 - __ Drive shaft boots (4WD/AWD)
 - ___ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Transfer case oil (4WD/AWD)

3

⋗

- ¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ² Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

48,750 MILES OR 39 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 52,500 Miles or 42 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

52,500 MILES OR 42 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - _____Axle & suspension parts
 - ____Brake calipers, pads, rotors
 - ____ Drive shaft boots (4WD/AWD)
 - Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Rotate tires (except G37 Sedan 2WD
- Sport, G37 Coupe 2WD Sport and
- G37 Convertible)

Equipment varies by model. Perform only those operations that apply to your vehicle.

56,250 MILES OR 45 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 60,000 Miles or 48 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

60,000 MILES OR 48 MONTHS

SCHEDULE 1 AND 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Replace climate controlled seat filter (M45/M35/FX50/FX35/ G37 Convertible, if so equipped)
- Replace engine air filter
- Replace engine coolant
- □ Replace in-cabin microfilter
- □ Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
- Automatic transmission fluid ^{1,3} Front suspension ball joints Fuel lines/connections
- Axle & suspension parts
- Brake lines & cables
- Brake calipers, pads, rotors
- Brake light and cruise control switches²
- Differential oil 1
- Drive shaft boots (4WD/AWD)
- Exhaust system

Propeller shaft (4WD/AWD/RWD) Steering gear and linkage Steering linkage ball joints

Fuel tank vapor vent system hoses

- Manual transmission oil 1
- Transfer case oil (4WD/AWD)¹
- ¹ Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

PREMIUM MAINTENANCE

Premium Maintenance adds the following services to Schedule 1 & 2:

- Lubricate all locks/hinges
- □ Replace automatic transmission fluid ³
- Replace differential oil
- Replace engine coolant
- Replace engine drive belts
- Replace manual transmission oil
- Replace radiator cap
- □ Replace transfer case oil (4WD/AWD)
- Replace wiper blades
- □ Inspect the following:
- All lights Headlights/adjust if necessary

63,750 MILES OR 51 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 67,500 Miles or 54 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

67,500 MILES OR 54 MONTHS

SCHEDULE 1 MAINTENANCE

- □ Replace engine oil and filter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - ____Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - __ Drive shaft boots (4WD/AWD)
 - Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Rotate tires (except G37 Sedan 2WD
- Sport, G37 Coupe 2WD Sport and
- G37 Convertible)

- Equipment varies by model. Perform only those operations that apply to your vehicle.
- For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

71,250 MILES OR 57 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 75,000 Miles or 60 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

75,000 MILES OR 60 MONTHS

SCHEDULE 1 MAINTENANCE

- □ Replace engine oil and filter
- □ Replace in-cabin microfilter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - ___ Automatic transmission fluid ²
 - ___ Axle & suspension parts
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches 1
 - __ Differential oil
 - __ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - __ Front suspension ball joints
 - __ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints
 - ____ Transfer case oil (4WD/AWD)

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- Replace in-cabin microfilter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - _ Automatic transmission fluid ²
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches ¹
 - __ Differential oil
 - __ Drive shaft boots (4WD/AWD)
 - ___ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ____ Transfer case oil (4WD/AWD)

- ¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- 2 Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission. Equipment varies by model. Perform only those operations that apply to your vehicle.
- For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

78,750 MILES OR 63 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 82,500 Miles or 66 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

82,500 MILES OR 66 MONTHS

SCHEDULE 1 MAINTENANCE

- □ Replace engine oil and filter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - ____Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - ___ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)

Equipment varies by model. Perform only those operations that apply to your vehicle.

86,250 MILES OR 69 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 90,000 Miles or 72 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

90,000 MILES OR 72 MONTHS

SCHEDULE 1 AND 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Replace climate controlled seat filter (M45/M35/FX50/FX35/
- G37 Convertible, if so equipped)
- Replace engine air filter
- Replace engine coolant
- □ Replace in-cabin microfilter
- □ Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
- Automatic transmission fluid ^{1,3} Front suspension ball joints Fuel lines/connections
- Axle & suspension parts
- Brake lines & cables
- Brake calipers, pads, rotors
- Brake light and cruise control switches²
- Differential oil 1
- Drive shaft boots (4WD/AWD)
- Exhaust system

- Fuel tank vapor vent system hoses Propeller shaft (4WD/AWD/RWD) Steering gear and linkage Steering linkage ball joints
 - Manual transmission oil 1
- Transfer case oil (4WD/AWD)¹

-Z ⋗ Z C S 0 Т C

 \leq

2

Z

- PREMIUM MAINTENANCE
- Premium Maintenance adds the following services to Schedule 1 & 2:
- Lubricate all locks/hinges
- □ Replace automatic transmission fluid ³
- Replace differential oil
- Replace engine coolant
- Replace engine drive belts
- Replace manual transmission oil
- Replace radiator cap
- □ Replace transfer case oil (4WD/AWD)
- Replace wiper blades
- □ Inspect the following:
- All lights Headlights/adjust if necessary

- ¹ Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

93,750 MILES OR 75 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 97,500 Miles or 78 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

97,500 MILES OR 78 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

- Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
 - ____Axle & suspension parts
 - ____ Brake calipers, pads, rotors
 - ____ Drive shaft boots (4WD/AWD)
 - Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Rotate tires (except G37 Sedan 2WD
- Sport, G37 Coupe 2WD Sport and G37 Convertible)

Equipment varies by model. Perform only those operations that apply to your vehicle.

101,250 MILES OR 81 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter


SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 105,000 Miles or 84 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

105,000 MILES OR 84 MONTHS

SCHEDULE 1 MAINTENANCE



- Replace in-cabin microfilter
- Replace spark plugs
- Rotate tires (except G37 Sedan 2WD) Sport, G37 Coupe 2WD Sport and G37 Convertible)

□ Inspect the following:

- Automatic transmission fluid ²
- Axle & suspension parts
- Brake lines & cables
- Brake calipers, pads, rotors
- Brake light & cruise control switches 1
- Differential oil
- Drive shaft boots (4WD/AWD)
- Exhaust system
- Front suspension ball joints
- Manual transmission oil
- Propeller shaft (4WD/AWD/RWD)
- Steering gear and linkage
- Steering linkage ball joints
- Transfer case oil (4WD/AWD)

□ Replace engine oil and filter Replace in-cabin microfilter Replace spark plugs Sport, G37 Coupe 2WD Sport and G37 Convertible) □ Inspect the following: Automatic transmission fluid 2 Brake lines & cables Brake calipers, pads, rotors Differential oil Drive shaft boots (4WD/AWD) Manual transmission oil Propeller shaft (4WD/AWD/RWD) Transfer case oil (4WD/AWD)

SCHEDULE 2 MAINTENANCE

Rotate tires (except G37 Sedan 2WD)

Brake light & cruise control switches 1

- ¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ² Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission.
- Equipment varies by model. Perform only those operations that apply to your vehicle.
- For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

108,750 MILES OR 87 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 112,500 Miles or 90 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

112,500 MILES OR 90 MONTHS

SCHEDULE 1 MAINTENANCE

 $\hfill\square$ Replace engine oil and filter

Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)

G37 Convertible)

□ Inspect the following:

- ___ Axle & suspension parts
- ___ Brake calipers, pads, rotors
- ___ Drive shaft boots (4WD/AWD)
- ___ Exhaust system
- ___ Front suspension ball joints
- ___ Propeller shaft (4WD/AWD/RWD)
- ___ Steering gear and linkage
- ___ Steering linkage ball joints

SCHEDULE 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and

G37 Convertible)

Equipment varies by model. Perform only those operations that apply to your vehicle.

116,250 MILES OR 93 MONTHS

SCHEDULE 1 MAINTENANCE

□ Replace engine oil and filter

SCHEDULE 2 MAINTENANCE

Next scheduled maintenance at 120,000 Miles or 96 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

120,000 MILES OR 96 MONTHS

SCHEDULE 1 AND 2 MAINTENANCE

- □ Replace engine oil and filter
- □ Replace climate controlled seat filter (M45/M35/FX50/FX35/ G37 Convertible, if so equipped)
- Replace engine air filter
- Replace engine coolant
- □ Replace in-cabin microfilter
- □ Rotate tires (except G37 Sedan 2WD Sport, G37 Coupe 2WD Sport and G37 Convertible)
- □ Inspect the following:
- Automatic transmission fluid ^{1,3} Front suspension ball joints Fuel lines/connections
- Axle & suspension parts
- Brake lines & cables
- Brake calipers, pads, rotors
- Brake light and cruise control switches²
- Differential oil 1
- Drive shaft boots (4WD/AWD)
- Exhaust system

- Fuel tank vapor vent system hoses Propeller shaft (4WD/AWD/RWD) Steering gear and linkage Steering linkage ball joints
 - Manual transmission oil 1
- Transfer case oil (4WD/AWD)¹

- PREMIUM MAINTENANCE
- Premium Maintenance adds the following services to Schedule 1 & 2:
- Lubricate all locks/hinges
- □ Replace automatic transmission fluid ³
- Replace differential oil
- Replace engine coolant
- Replace engine drive belts
- Replace manual transmission oil
- Replace radiator cap
- □ Replace transfer case oil (4WD/AWD)
- Replace wiper blades
- □ Inspect the following:
- All lights Headlights/adjust if necessary

- ¹ Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission and the M35/EX35 with 5-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

3,750 Miles or 3 Months	7,500 Miles or 6 Months	11,250 Miles or 9 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
15,000 Miles or 12 Months	18,750 Miles or 15 Months	22,500 Miles or 18 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
26,250 Miles or 21 Months	30,000 Miles or 24 Months	33,750 Miles or 27 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:

37,500 Miles or 30 Months	41,250 Miles or 33 Months	45,000 Miles or 36 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
48,750 Miles or 39 Months	52,500 Miles or 42 Months	E6 250 Milos or 45 Months
		56,250 Miles or 45 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
60,000 Miles or 48 Months	63,750 Miles or 51 Months	67,500 Miles or 54 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	 Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:

71,250 Miles or 57 Months	75,000 Miles or 60 Months	78,750 Miles or 63 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
82,500 Miles or 66 Months	86,250 Miles or 69 Months	90,000 Miles or 72 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
93,750 Miles or 75 Months	97,500 Miles or 78 Months	101,250 Miles or 81 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:

105,000 Miles or 84 Months	108,750 Miles or 87 Months	112,500 Miles or 90 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
116,250 Miles or 93 Months	120,000 Miles or 96 Months	
116,250 Miles or 93 Months Dealer Name:	120,000 Miles or 96 Months Dealer Name:	
Dealer Name:	Dealer Name:	
Dealer Name: Date:	Dealer Name: Date:	
Dealer Name:	Dealer Name:	
Dealer Name: Date: Mileage:	Dealer Name: Date: Mileage:	

Notes:



