

2011 Infiniti FX

Quick Reference Guide



INFINITI.



- 01** INSTRUMENT BRIGHTNESS CONTROL*
- 02** TRIP COMPUTER SWITCHES*
- 03** LOW TIRE PRESSURE WARNING LIGHT
- 04** PADDLE SHIFTERS*
- 05** HEADLIGHT AND TURN SIGNAL CONTROL
- 06** WINDSHIELD WIPER / WASHER SWITCH
- 07** TRIP A/B RESET BUTTON*
- 08** STEERING WHEEL SWITCHES FOR AUDIO / BLUETOOTH®
- 09** INTELLIGENT CRUISE CONTROL (FULL-SPEED RANGE)
- 10** OUTSIDE MIRROR CONTROL SWITCH
- 11** INTELLIGENT BRAKE ASSIST (IBA) SWITCH*
- 12** POWER LIFTGATE OPENER
- 13** POWER DOOR ON/OFF SWITCH*
- 14** DISTANCE CONTROL ASSIST / LANE DEPARTURE PREVENTION (DCA/LDP) BUTTON*
- 15** TILT/TELESCOPIC STEERING WHEEL SWITCH*
- 16** FORWARD COLLISION WARNING / LANE DEPARTURE WARNING (FCW/LDW) BUTTON*
- 17** VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH*
- 18** INTELLIGENT KEY PORT*
- 19** HOOD RELEASE*
- 20** CONTROL PANEL DISPLAY SCREEN*
- 21** AUDIO SYSTEM
- 22** AUTOMATIC CLIMATE CONTROLS
- 23** FRONT PASSENGER AIR BAG STATUS LIGHT*

*See your Owner's Manual for more information.

new system features

Power Liftgate Opener Switch (if so equipped)	2
Power Door Main Switch (if so equipped)	2
Garage Mode System (if so equipped)	2

essential information

Loose Fuel Cap	3
Tire Pressure Monitoring System (TPMS)	3

first drive features

INFINITI Intelligent Key™ System	4
Power Seat Adjustments	4
Automatic Drive Positioner (if so equipped)	5
Outside Mirror Control Switch	5
Starting/Stopping the Engine	6
Headlight Control Switch	6
Windshield Wiper Switch	6
Climate Controls	7
FM/AM/XM® Radio with CD/DVD Player (if so equipped)	7
Parking Brake	8
Power Liftgate (if so equipped)	8
Fuel-Filler Door	8

system guide

Cruise Control	9
Bluetooth® Hands-free Phone System	9
Navigation System (if so equipped)	9
DVD Entertainment System (if so equipped)	10
HomeLink® Universal Transceiver	10



- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the “**Safety — Seats, seat belts and supplemental restraint system (section 1)**” of your Owner’s Manual.



Additional information about your vehicle is also available in your Owner’s Manual, Navigation System Owner’s Manual and at www.InfinityUSA.com.


This easy-to-use Quick Reference Guide is intended to help you more fully appreciate some of the unique features and functions of your new vehicle. However, it is not intended to replace your Owner’s Manual. The Owner’s Manual contains more detailed information to help you better understand the important safety warnings, features, operation and maintenance of your vehicle. All information, specifications, photographs and illustrations in this publication are those in effect at the time of printing. INFINITI reserves the right to change specifications or design without notice and without obligation.

new system features

Power Liftgate Opener Switch (if so equipped)

- When the liftgate is closed, the liftgate will open automatically by pushing the power liftgate switch **01** on the instrument panel.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



Power Door Main Switch (if so equipped)

- The power liftgate operation can be turned on or off by the power door main switch **02** on the instrument panel.
- When the power liftgate main switch is pushed to the **OFF** position, power operation is not available using the power liftgate switch **01**.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.




Garage Mode System (if so equipped)

- Your vehicle’s power liftgate operation can be set to stop opening at a predetermined position in order to help avoid damaging the liftgate or overhead objects.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.

Loose Fuel Cap

- A LOOSE FUEL CAP warning message will appear in the dot matrix liquid crystal display **01** when the fuel-filler cap is not tightened correctly.
- Turn the fuel-filler cap clockwise until it clicks.
- The warning message will disappear when the vehicle detects the fuel-filler cap is properly tightened and the reset button **02** is pressed.
- If the cap is not properly tightened, the Malfunction Indicator Light SERVICE ENGINE SOON may illuminate.



For more information, refer to the “**Instruments and controls (section 2)**” and the “**Pre-driving checks and adjustment (section 3)**” of your Owner’s Manual.

Tire Pressure Monitoring System (TPMS)

- A CHECK TIRE PRESSURE warning message will appear in the dot matrix liquid crystal display **01** and the TPMS light will illuminate when one or more tires are low on pressure and air is needed.
- After tire pressures are adjusted, drive the vehicle at speeds above 16 MPH (25 km/h) and the warning and indicator light will disappear.
- When the low tire pressure warning light flashes for approximately 1 minute and then remains on, the TPMS is not functioning properly. Have the system checked by an INFINITI dealer.
- Tire pressure rises and falls depending on the heat caused by the vehicle’s operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire, which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light to illuminate. If the warning light illuminates in low ambient temperature, check the tire pressure in all four tires.



For more information, refer to the “**Instruments and controls (section 2)**” and the “**Starting and driving (section 5)**” of your Owner’s Manual.

first drive features

INFINITI Intelligent Key™ System

The INFINITI Intelligent Key™ System allows you to lock or unlock your vehicle, open your liftgate and start the engine.

- To lock or unlock the driver's or front passenger's door, push the door handle request switch **01** once.
- Push the door handle request switch **01** within 1 minute of unlocking the door and all other doors will unlock.

NOTE: It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

For more information, refer to the **"Pre-driving checks and adjustments (section 3)"** of your Owner's Manual.



Power Seat Adjustments

- Push the control switch **01** forward or backward to slide the seat forward or backward.
- Push the switch **02** forward or backward to adjust the angle of the seatback.

SEAT LIFTER

- To adjust the height and angle of the seat, push the front or rear end of the switch **01** up or down.

LUMBAR SUPPORT

- To adjust the seat's lumbar area, push either end of the switch **03**.



For more information, refer to the **"Safety — Seats, seat belts and supplemental restraint system (section 1)"** of your Owner's Manual.

Automatic Drive Positioner (if so equipped)


- Two positions for the driver's seat, steering column and outside mirrors can be stored in the automatic drive positioner memory.
- Follow these procedures to set the memory positions:
 - Confirm the shift lever is in the P (PARK) position.
 - Push the ignition switch to the **ON** position.
 - Adjust the driver's seat, steering column and outside mirrors to the desired positions using the adjusting switches for each feature.
 - Push the **SET** switch and within 5 seconds, push the memory switch (**1** or **2**) for at least 1 second.
 - The indicator light on the memory switch you select will illuminate for approximately 5 seconds.
 - The driver's seat, steering column and outside mirror positions are now set to your preference.
- These memorized positions can also be linked to your INFINITI Intelligent Key™.



For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.

Outside Mirror Control Switch

- Move the control switch **01** right or left to select the right or left side mirror.
- Adjust each mirror to the desired position using the switch **02**.
- Push the switch **03** to the **CLOSE** position to fold the outside rearview mirrors and push the switch **03** to the **OPEN** position to unfold the outside rearview mirrors.



For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.

first drive features

Starting/Stopping the Engine

- Depress the brake pedal.
- Press the ignition switch **START/STOP** button to start the engine.

NOTE: It is important to make sure the INFINITI Intelligent Key™ is with you (that is, in your pocket or purse).

TURNING THE ENGINE OFF

- Move the shift lever to the P (PARK) position and apply the parking brake.
- Press the ignition switch **START/STOP** button to turn the engine off.

EMERGENCY ENGINE SHUT OFF

To shut off the engine in an emergency situation while driving, perform one of the following procedures:

- Rapidly push the push button ignition switch 3 consecutive times, or
- Push and hold the push button ignition switch for more than 2 seconds.

For more information, refer to the "**Starting and driving (section 5)**" of your Owner's Manual.



Headlight Control Switch

- Turn the headlight control switch **01** to the $\equiv \square \square$ position to turn on the front parking, side marker, tail, license plate and instrument panel lights.
- Turn the switch **01** to the $\equiv \square$ position to turn on the headlights.

For more information, refer to the "**Instruments and controls (section 2)**" of your Owner's Manual.



Windshield Wiper Switch

- Move the lever to the following positions to operate the windshield wipers:
 - 01** Intermittent (**INT**) – Operates the speed-sensing and rain-sensing (if so equipped) front wipers intermittently.
 - 02** Low (**LO**) – Front wipers operate at a continuous low-speed.
 - 03** High (**HI**) – Front wipers operate at a continuous high-speed.
 - 04** Rear Wiper (**REAR**) – Twist the end of the lever to operate the first (**INT**) or second (**ON**) speed settings for the rear wiper.



For more information, refer to the "**Instruments and controls (section 2)**" of your Owner's Manual.

Climate Controls



01 AUTO BUTTON/TEMPERATURE CONTROL KNOB

Press the **AUTO** button to turn the system on and the fan speed, air flow distribution and temperature will be automatically maintained. Turn the driver's side temperature control knob left for cooler air or right for warmer air.

02 FAN SPEED CONTROL BUTTONS

Press the fan speed control buttons to manually adjust the fan speed up or down .

03 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

Press the front defroster button to turn the system on or off.

04 DEFROSTING REAR WINDOW AND OUTSIDE MIRRORS

Push the rear window and outside mirror defroster switch to turn the system on or off.

For more information, refer to the “**Instruments and controls (section 2)**” or the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner's Manual.

FM/AM/XM[®]* Radio With CD/DVD Player (if so equipped)



01 ON/OFF VOLUME CONTROL KNOB

Press the **VOL** knob to turn the system on or off. Turn the knob right or left to increase or decrease the volume.

02 TUNE/FOLDER/AUDIO CONTROL KNOB

To manually tune the radio, turn the **TUNE/FOLDER/AUDIO** knob left or right.

*XM[®] Satellite Radio is only available on vehicles equipped with optional XM[®] satellite subscription service.


For more information, refer to the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner's Manual.

first drive features

Parking Brake

- To apply, firmly depress the parking brake pedal **01** .
- To release, firmly press the foot brake **02** , then press the parking brake pedal **01** and the parking brake will release.

For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.




Power Liftgate (if so equipped)

When the liftgate is closed, the liftgate will open automatically by:

- Pushing the power liftgate switch **01** on the instrument panel.
- Pushing the liftgate opener switch **02** .
- Pressing the power liftgate button **03** on the INFINITI Intelligent Key™ for more than one second.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



Fuel-Filler Door

The fuel-filler door is located on the right, rear side of the vehicle.

- When the doors of the vehicle are locked or unlocked, the fuel-filler door is automatically locked or unlocked at the same time.
- To open the fuel-filler door, once unlocked, push the left side of the door and release.



For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.

Cruise Control

- The cruise control system enables you to set a constant cruising speed.
- The system will automatically maintain the set speed until you tap the brake pedal, accelerate, cancel or turn the system off.

For more information, refer to the **"Starting and driving (section 5)"** of your Owner's Manual.



Bluetooth® Hands-free Phone System

- With an overhead microphone and sound transmitted through the audio system speakers, the Bluetooth® Hands-free Phone System utilizes Bluetooth wireless technology and voice recognition to provide hands-free cellular phone communication.

For more information, refer to the **"Monitor, climate, audio, phone and voice recognition systems (section 4)"** of your Owner's Manual or please visit www.InfinitiUSA.com/bluetooth.



Navigation System (if so equipped)



- Your Navigation System can calculate a route from the current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- The Navigation System will continually update your vehicle's position. If you have deviated from the original route, it will recalculate the route from your current location.
- The Navigation System can also provide you with important data, such as; distance to empty, your tire rotation schedule and other maintenance interval reminders.

For more information, please refer to your Navigation System Owner's Manual.

DVD Entertainment System (if so equipped)

- With this Entertainment System, you can play video files via a DVD or CD, providing images and sound from the control panel.
- You can also operate auxiliary devices such as video games, camcorders or portable video players through the auxiliary jacks.
- To view movies on the control panel, stop the vehicle in a safe location, move the shift lever to the P (PARK) position and apply the parking brake.
- To reduce driver distraction, movies will not be shown on the front display while the vehicle is in any drive position.

For more information, refer to the **"Monitor, climate, audio, phone and voice recognition systems (section 4)"** of your Owner's Manual.



HomeLink® Universal Transceiver



- The HomeLink® system can learn and consolidate the functions of up to three different hand-held transmitters, operating items such as; garage doors, property gates, outdoor and indoor lights or alarm systems.

For more information, refer to the **"Instruments and controls (section 2)"** of your Owner's Manual, the HomeLink® website at www.homelink.com or call 1-800-355-3515.



I N F I N I T I .

All illustrations, photographs and specifications in this guide are based on the latest product information; some vehicle parts cannot be shown in certain photographs. Some vehicles are shown with optional equipment. See actual vehicles for complete accuracy. Infiniti Division of Nissan North America, Inc. reserves the right to make changes at any time, without notice, to prices, colors, materials, equipment, specifications and models, and to discontinue models or equipment. Availability and delivery time for particular models and equipment combinations may vary. For information on availability, additional options or accessories, contact your Infiniti dealer. All specifications, options and accessories shown in this guide apply to the 49 continental states. Specifications, options and accessories may differ in Hawaii, U.S. territories and other countries. INFINITI, the Infiniti logo and INFINITI model names are Nissan trademarks.