2011 Infiniti Service and Maintenance Guide



VEHICLE IDENTIFICATION

Vehicle Identification Number (VIN)	
Delivery Date	Warranty Start Date
Mileage at Delivery	Model Year
Selling Dealer	Selling Dealer Phone

TABLE OF CONTENTS



OWNER'S LITERATURE INFORMATION2

INTRODUCTION

Infiniti Maintenance	3
Why Infiniti Service?	4
Extended Service Products	5
Genuine Infiniti Collision Parts	6

SCHEDULED MAINTENANCE GUIDE

Determining the Proper Maintenance Interval7
Explanation of Scheduled Maintenance Items
Maintenance Schedules11
Maintenance Log

OWNER'S LITERATURE INFORMATION

INDEX OF TOPICS

WHERE TO FIND INFORMATION

Radio/CD/Heater/AC Operation
Starting and Driving Your Vehicle
Security System Operation
Changing a Flat Tire
New Vehicle Limited Warranty
Federal Emission Control Warranties
California Emission Control Warranties
Tire Pressure/Rotation
Tire Warranties/Safety Information
Consumer Affairs Assistance
Customer Care/Lemon Law Information Booklet: page 5*
Do It Yourself Information
General Maintenance

2 * Not applicable outside of the United Sates.

INFINITI MAINTENANCE



Maintain Your Investment

Preventative scheduled maintenance is an important investment to optimize the performance, durability, reliability, safety and resale value of your Infiniti. Scheduling your vehicle's maintenance at the recommended intervals will ensure your vehicle is running at its best.

We want you to enjoy your Infiniti vehicle. This Service and Maintenance Guide is designed to help you make sure your vehicle receives proper and timely maintenance that is necessary. Key services are explained in detail, along with an outline of scheduled maintenance to help you maintain your vehicle. Your local Infiniti dealer can assist you in determining the best schedule based on your driving habits and local conditions.

Failure to perform scheduled maintenance may result in excluding portions of your vehicle from warranty coverage and may reduce the performance, durability, reliability, safety and/or resale value of your vehicle. See your Warranty Information Booklet and Owner's Manual for details.

WHY INFINITI SERVICE?*

To preserve the quality and safety of your vehicle, an authorized Infiniti dealer is recommended for maintenance or repair. Only an authorized Infiniti dealer offers you these advantages:

- Factory Trained and ASE certified technicians
- Immediate access to warranty service history and factory technical information
- Latest diagnostic, special tools and service techniques
- Genuine Infiniti Parts that meet Infiniti's demanding standards
- 12 month/12,000 mile parts and labor limited warranty when Genuine Infiniti Parts are installed by your dealer
- Complimentary Multi-Point Inspections (at participating dealers)
- Clear, up-front estimates
- Service Loan Car availability for scheduled warranty service.**
- Shuttle service/Courtesy van (at participating dealers)



Your Service – Your Way

We recommend relying on our trained Infiniti service specialists, who refer to their detailed knowledge of your Infiniti in every service they perform. Plus, they use Genuine Infiniti Parts, designed and engineered specifically to maintain your Infiniti's original integrity. That's the distinction of your authorized Infiniti dealer.

* May differ or not apply outside the United States, please inquire of your dealer.

**Available during Basic New Vehicle Limited Warranty at participating Infiniti dealers. Subject to availability. Restrictions apply.



Infiniti Elite Extended Protection Plan*

Long Term Coverage

The Infiniti Elite Extended Protection Plan provides you with long term coverage to 7 years/100,000 miles. Coverage under the optional Infiniti Elite Extended Protection Plan and the Infiniti Limited Warranties begins with the delivery of the vehicle to the first retail buyer. Accordingly, your agreement may provide coverage for your vehicle for a portion of the same period as your New Vehicle Warranty. Upon expiration of the applicable Limited Warranties, the full spectrum of the Infiniti Elite Extended Protection Plan coverage is in force to the end of the time or mileage term. During the period of your Basic Warranty, the Infiniti Elite Extended Protection Plan provides you with Rental Car Coverage only.

New Vehicle Limited Warranty

Elite Infiniti Extended Protection Plan (7 years/100,000 miles) benefits include:

mechanical breakdown protection

Roadside Assistance extended

car rental coverage

* This product is not available outside the United States.

Benefits You Can Count On

SERVICE AT AUTHORIZED INFINITI DEALERSHIPS/REPAIR FACILITIES.

With the Infiniti Elite Extended Protection Plan, service is completed by Infiniti trained technicians.

UNLIMITED CLAIMS.

No limit on the number of claims for covered repairs.

PROVIDES FOR THE COST OF GENUINE ORIGINAL EQUIPMENT REPLACEMENT PARTS.

Designed for use on Infiniti vehicles. No inferior substitutes.

EMERGENCY TOLL-FREE HELP.

If a breakdown occurs outside your area, you are covered. Just contact the nearest Infiniti dealer, or call the special toll-free number for assistance.

SUBSTITUTE TRANSPORTATION.

If a mechanical breakdown occurs and you require alternate transportation, Infiniti will reimburse you for actual expenses up to \$50 per day, to a maximum of 5 days and \$250 per service visit.

TRANSFERABLE TO A NEW OWNER.

Should you sell your Infiniti before your coverage expires, you can transfer your Infiniti Elite Extended Protection Plan**, thereby enhancing resale value.

CONVENIENT AND ECONOMICAL. Coverage that costs only pennies per day. Your Infiniti dealer will be happy to include the cost in your monthly car payment.

^{**} A nominal transfer fee may apply. For details please refer to the Infiniti Elite Extended Protection Plan Service Agreement or contact your Infiniti dealer.

GENUINE INFINITI COLLISION PARTS

If you have an accident, insist on Genuine Infiniti Collision Parts. If you want your vehicle to be restored using parts made to Infiniti's original exacting specifications – if you want it to last, help to protect your personal safety and to help hold its resale value, the solution is simple. Tell your insurance agent and your repair shop to use only Genuine Infiniti Collision Parts.

Many non-genuine parts are copies made from impressions of Infiniti parts and may not match the specifications and performance standards of Genuine Infiniti Parts. As a result, non-genuine parts may not look or fit right, and may be less safe.

The hood on your vehicle is a good example. Infiniti designed it with hood buckling creases to help prevent the hood from penetrating the interior of your vehicle in an accident. Non-genuine parts may not provide such built-in safeguards.

In some states, the law says you must be advised if non-genuine parts are used to repair your vehicle. **Why should you take a chance?**

Replacement Panel Limited Lifetime Corrosion Warranty*

See your participating Infiniti dealer for details.

If you have your collision damage repaired using Genuine Infiniti Outer Sheet Metal Panels you don't have to worry about corrosion. That's because these panels are warranted against inside out rust-through perforation for as long as you own your Infiniti. Another reason to insist on Genuine Infiniti Collision Repair Parts.

^{*} This warranty does not apply to vehicles or parts, not distributed by Nissan North America and/or sold outside the United States.

DETERMINING THE PROPER MAINTENANCE INTERVAL

As a condition of your vehicle's warranty, you are responsible for properly maintaining your vehicle. In maintaining your vehicle, you should follow either Schedule 1 or Schedule 2 as listed below. Use these guidelines to determine which maintenance schedule to use.

SCHEDULE 1 (more severe operating conditions), every 3,750 miles or 3 months, whichever comes first

Use Schedule 1 if you primarily operate your vehicle under any of these conditions:

- Repeated short trips of less than 5 miles in normal temperatures or less than 10 miles in freezing temperatures
- Stop-and-go traffic in hot weather or lowspeed driving for long distances
- Driving in dusty conditions or on rough, muddy, or salt-spread roads
- Towing a trailer, or using a camper or car-top carrier

SCHEDULE 2 (less severe operating conditions), every 7,500 miles or 6 months, whichever comes first

Schedule 2 features 7,500-mile service intervals; with Schedule 2 <u>fewer</u> maintenance items are regularly checked or replaced than with Schedule 1.

Generally, Schedule 2 applies only to highway driving in temperate conditions. Use Schedule 2 only if you primarily operate your vehicle under conditions other than those listed in Schedule 1.

PREMIUM MAINTENANCE*

Premium Maintenance is an Infinitirecommended optional upgrade that adds services to Schedule 1 and 2 when maintenance is performed.

Performing the Premium upgrade services may optimize the performance, durability, reliability, and resale value of your vehicle. (Premium Maintenance items are available at every 30,000 miles or 24 month interval.)

*Premium Maintenance is an Infiniti-recommended option; however, you need not perform such maintenance in order to maintain the warranties which come with your Infiniti. Premium Maintenance may not be available outside the United States, please inquire of your dealer.

EXPLANATION OF SCHEDULED MAINTENANCE ITEMS

The following descriptions are provided to give you a better understanding of the scheduled maintenance items that should be regularly checked or replaced. The maintenance log indicates at which mileage/time intervals each item requires service.

In addition to scheduled maintenance, your Infiniti requires that some items be checked during normal day-to-day operation. You can find these items listed under "General Maintenance" in Chapter 8 of your Owner's manual.

Items marked with **"*"** are recommended by Infiniti for reliable vehicle operation. You are not required to perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

When applicable, additional information can be found in the "Do-it-yourself" section in Chapter 8 of your Owner's Manual. **NOTE:** Nissan North America does not advocate the use of non-OEM approved aftermarket flushing systems and strongly advises against performing these services on a Infinti product. Many of the aftermarket flushing systems use non-OEM approved chemicals or solvents, the use of which has not been validated by Nissan North America.

For recommended fuel, lubricants, fluids, grease, and refrigerant refer to Chapter 9 in your Owner's Manual.

Emission Control System Maintenance:

Drive Belts*

Check engine drive belts for wear, fraying or cracking and for proper tension. Replace any damaged drive belts.

Engine Air Filter

Replace at specified intervals. When driving for prolonged periods in dusty conditions, check/replace the filter more frequently.

Engine Coolant*

Replace coolant at the specified interval. When adding or replacing coolant, be sure to use only Genuine Nissan Long Life Antifreeze/Coolant (Blue) or equivalent with the proper mixture. (Refer to the owner's manual to determine the proper mixture for your area). The recommended service interval of the factory-fill coolant is 105,000 miles (168,000km) or 7 years whichever comes first. Subsequent replacement of Genuine Nissan Long Life Antifreeze/Coolant (Blue) should occur every 75,000 miles (120,000km) or 5 years whichever comes first. NOTE: Mixing any other type of coolant or the use of non-distilled water will reduce the recommended service interval of the coolant.

Engine Oil and Oil Filter

Replace engine oil and oil filter at the specified intervals. For recommended oil grade and viscosity refer to Chapter 9 in your Owner's Manual.

EXPLANATION OF SCHEDULED MAINTENANCE ITEMS

Engine Valve Clearance*

Inspect only if valve noise increases. Adjust valve clearance if necessary.

Evaporative Emissions Control Vapor Lines*

Check vapor lines and connections for leaks or looseness. Tighten connections or replace parts as necessary.

Fuel Filter

Maintenance-free item (In-tank type filter).

Fuel Lines*

Check the fuel hoses, piping and connections for leaks, looseness, or deterioration. Tighten connections or replace parts as necessary.

Spark Plugs

Replace at specified intervals. Install new plugs of the same type as originally equipped.

Chassis and Body Maintenance:

Brake Lines and Cables

Visually inspect for proper installation.

Check for chafing, cracks, deterioration, and signs of leaking. Replace any deteriorated or damaged parts immediately.

Brake Light and Cruise Control Switches

Inspect the clearance between the brake pedal and the switches.

Brake Calipers, Pads, Rotors

Check for wear, deterioration and fluid leaks. Replace any deteriorated or damaged parts immediately.

Exhaust System

Visually inspect the exhaust pipes, muffler and hangers for leaks, cracks, deterioration, and damage. Tighten connections or replace parts as necessary.

In-Cabin Microfilter

Replace at specified intervals. When driving for prolonged periods in dusty conditions, replace the filter more frequently.

Propeller Shaft(s)

Check for damage, looseness, and grease leakage (4WD/AWD/RWD).

Steering Gear and Linkage, Axle and Suspension Parts, Drive Shaft Boots

Check for damage, looseness, and leakage of oil or grease. Under severe driving conditions, inspect more frequently.

Tire Rotation

Tires should be rotated every 7,500 miles according to the instructions in the Owner's Manual (except G37 Sedan Journey Model with Sport Package, G37 Sedan Sport 6MT, G37 Coupe Journey model with Sport Package, G37 Coupe Sport 6MT, G37 Coupe Journey models with Performance Tire & Wheel Package and all G37 convertibles). When rotating tires, check for damage and uneven wear. Replace if necessary.

Transmission Fluid – Automatic or Manual, Differential Oil, Transfer Case Oil

Visually inspect for signs of leakage at specified intervals. If towing a trailer, using a camper or car-top carrier, or driving on rough or muddy roads, replace the transmission fluid/oil at every 30,000 miles or 24 months (except models with 7-speed automatic transmission).

OFF-ROAD MAINTENANCE (QX56 ONLY)

Check the following items more frequently after driving off-road through deep sand, mud or water:

- Brake pads and rotors
- Brake lines and hoses
- Differential oil, transmission fluid, and transfer case oil
- Steering linkage
- Propeller shafts and drive shafts
- Engine air filter
- In-cabin microfilter

MAINTENANCE SCHEDULES



The following Maintenance Schedule has been compiled by Infiniti to assist you in performing the recommended maintenance services and keeping appropriate records of services performed. Along with the related repair invoices, receipts, and other such records, a properly documented maintenance history could enhance the value of your vehicle should you ever wish to sell it. The services listed represent the minimal factory recommended requirements for each time/mileage interval, up to 120,000 miles / 96 months.

Beginning on page 46 you will find a maintenance log that should be used to track when and where services were performed. Ask your Service Consultant to stamp and update your log each time your vehicle is serviced.

COMPLIMENTARY MULTI-POINT INSPECTION* For the ultimate in preventative maintenance,

ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer.

MPI's are performed by Infiniti factory trained Technicians who will provide you with a detailed report of your vehicles condition.

Driving your Infiniti should be as worry-free an experience as possible. Trust your Infiniti dealership to inspect and maintain your vehicle so you can take pride in knowing your vehicle is ready for the road ahead.

*Available at participating dealers

COMPLIMENTARY MULTI-POINT INSPECTION*

			Multi-Poi	IN FINITI			
				Nodel: Date:			
ilea	ge	:		Work Order #:			
ervi	ce	Сог	nsultant:	Technician:			
CHE	ск	ED /	AND OKAY	CHECKED AND OKAY			
Г	M		IEED FUTURE ATTENTION	MAY NEED FUTURE ATTENTION			
L	1	R	EQUIRES IMMEDIATE ATTENTION	REQUIRES IMMEDIATE ATTENTION			
Ľ	1		INTERIOR / EXTERIOR	BATTERY PERFORMANCE			
1		1	Head Lights / Tail Lights / Turn Signals / Brake Lights Hazard Warning Lights / Exterior Lamps	24 24 24 Battery Terminals / Cables / Mountings			
	2	2	Windshield Washer Spray / Wiper Blades	25 25 25 Check Condition of Battery (Storage Capacity Test)			
	3	3	Windshield Condition (Inspect for Cracks, Chips, or Fitting)	Pass Recharge Retest Fail Date Code			
t		4	Upholstery / Carpet / Floor Mats / Mirrors / Glass	BRAKE Brake Inspection Not Performed This Visit			
	5	5	Emergency Brake Adjustment	26 26 26 Left Front Brake Lining mm			
t		6	Hom Operation	26 26 26 Left Rear Brake Lining mm			
	7	7	Fuel Tank Cap Gasket	26 26 26 Right Front Brake Lining mm			
	3	8	In-Cabin Microfilter (if equipped)	26 26 26 Right Rear Brake Lining mm			
	,	9	Clutch Operation (if equipped)	TIRE			
t			UNDER VEHICLE	Left Front Right Front			
1	0	10	Shock Absorbers / Suspension	27 27 27 Tire Tread32nds 27 27 27 Tire Tread32nds			
1 1	1	11	Steering Gear Box / Linkage and Boots / Ball Joints / Dust Covers	27 27 27 Wear Pattern 27 27 27 Wear Pattern			
2 1	2	12	Muffler / Exhaust Pipes / Mountings	27 27 27 Tire Pressurepsi 27 27 27 Tire Pressurepsi			
3 1	3	13	Engine Oil and/or Fluid Leaks	Left Rear Right Rear			
4 1	4	14	Brake Lines / Hoses / Parking Brake Cable	27 27 27 Tire Tread32nds 27 27 27 Tire Tread32nds			
5 1	5	15	Drive Shaft Boots / Constant Velocity Boots / U-Joints / Transmission Linkage (if equipped)	27 27 27 Wear Pattern 27 27 Wear Pattern			
5 1	6	16	Transmission / Differential / Transfer Case (Check Fluid Level, Ruid Condition and Fluid Leaks)	27 27 27 Tire Pressurepsi 27 27 Tire Pressurepsi			
7 1	7	17	Fuel Lines and Connections / Fuel Tank Band / Fuel Tank Vapor Vent System Hoses	COMMENTS / ESTIMATES			
E			UNDER HOOD	COMMENTS / ESTIMATES			
8 1	8	18	Fluid Levels: Oil / Coolant / Battery / Power Steering / Brake / Washer / Automatic Transmission				
9 1	9	19	Engine Air Filter				
0 2	0	20	Drive Belts (condition and adjustment)				
1 2	1	21	Engine Coolant System				
2 2	2	22	Cooling System Hoses / Heater Hoses / Air Conditioning Hoses and Connections				
2 2	3	23	Radiator Core and Cap				

NOTE: Form shown is an example. Actual form may vary.

3,750 MILES OR 3 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 7,500 Miles or 6 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

7,500 MILES OR 6 MONTHS

SCHEDULE 1 (MORE SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - __ Drive shaft boots (4WD/AWD)
 - __ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)

E

3

⋗

Equipment varies by model. Perform only those operations that apply to your vehicle.

11,250 MILES OR 9 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 15,000 Miles or 12 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

15,000 MILES OR 12 MONTHS

SCHEDULE 1 (MORE SEVERE)

- □ Replace engine oil and filter
- Replace brake fluid
- Replace in-cabin microfilter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - Automatic transmission fluid 2
 - Axle & suspension parts
 - Brake lines & cables
 - Brake calipers, pads, rotors
 - Brake light & cruise control switches 1 Differential oil

 - Drive shaft boots (4WD/AWD)

- Exhaust system
- Front suspension ball joints
- Manual transmission oil
- Propeller shaft (4WD/AWD/RWD)
- ___ Steering gear and linkage
- Steering linkage ball joints
- ____ Transfer case oil (4WD/AWD)

SCHEDULE 2 (LESS SEVERE)

- □ Replace engine oil and filter
- Replace in-cabin microfilter
- □ Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - Automatic transmission fluid 2
 - Brake lines & cables
 - Brake calipers, pads, rotors
 - Brake light & cruise control switches 1
 - Differential oil
 - Drive shaft boots (4WD/AWD)
 - Manual transmission oil
 - Propeller shaft (4WD/AWD/RWD)
 - Transfer case oil (4WD/AWD)

¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible). Equipment varies by model. Perform only those operations that apply to your vehicle.

² Except models with 7-speed automatic transmission. Equipment varies by model. Perform only those operations that apply to your vehicle.

18,750 MILES OR 15 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 22,500 Miles or 18 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

22,500 MILES OR 18 MONTHS

SCHEDULE 1 (MORE SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - __ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

Replace engine oil and filter
 Rotate tires (refer to page 9 for exceptions)

Equipment varies by model. Perform only those operations that apply to your vehicle.

26,250 MILES OR 21 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 30,000 Miles or 24 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

MAINTENANCE SCH

EDULE

30,000 MILES OR 24 MONTHS

SCHEDULE 1 AND 2	OPTIONAL PREMIUM UPGRADE
 Replace engine oil and filter Replace brake fluid Replace engine air filter Replace in-cabin microfilter Rotate tires (refer to page 9 for exceptions) Inspect the following: Automatic transmission fluid ^{1,3} Front suspension ball joints Axle & suspension parts Fuel lines/connections Brake lines & cables Fuel tank vapor vent system hoses Brake calipers, pads, rotors Propeller shaft (4WD/AWD/RWD) Brake light and cruise control switches² Steering gear and linkage sall joints Differential oil ¹ Manual transmission oil ¹ Drive shaft boots (4WD/AWD) Transfer case oil (4WD/AWD) ¹ 	Premium Upgrade adds the following services to Schedule 1 & 2: Lubricate all locks/hinges Replace automatic transmission fluid ³ Replace differential oil Replace engine drive belts Replace manual transmission oil Replace radiator cap Replace transfer case oil (4WD/AWD) Replace wiper blades Inspect the following: All lights Headlights/adjust if necessary

- Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

33,750 MILES OR 27 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 37,500 Miles or 30 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

37,500 MILES OR 30 MONTHS

SCHEDULE 1 (MORE SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - ___ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - __ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)

Equipment varies by model. Perform only those operations that apply to your vehicle.

41,250 MILES OR 33 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 45,000 Miles or 36 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

45,000 MILES OR 36 MONTHS

SCHEDULE 1 (MORE SEVERE)

- Replace engine oil and filter
- Replace brake fluid
- □ Replace in-cabin microfilter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ____ Automatic transmission fluid ²
 - ____ Axle & suspension parts
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches ¹
 - __ Differential oil
 - ___ Drive shaft boots (4WD/AWD)
 - __ Exhaust system
 - ___ Front suspension ball joints
 - __ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - __ Steering linkage ball joints
 - ___ Transfer case oil (4WD/AWD)

SCHEDULE 2 (LESS SEVERE)

- □ Replace engine oil and filter
- □ Replace in-cabin microfilter
- Rotate tires (refer to page 9 for exceptions)
- Inspect the following:
 - ____ Automatic transmission fluid ²
 - ___ Brake lines & cables
- ___ Brake calipers, pads, rotors
- Brake light & cruise control switches ¹
 Differential oil
- ___ Drive shaft boots (4WD/AWD)
- ___ Manual transmission oil
- Propeller shaft (4WD/AWD/RWD)
- ___ Transfer case oil (4WD/AWD)

3

- ¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ² Except models with 7-speed automatic transmission. Equipment varies by model. Perform only those operations that apply to your vehicle.
- □ For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

48,750 MILES OR 39 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 52,500 Miles or 42 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

52,500 MILES OR 42 MONTHS

SCHEDULE 1 (MORE SEVERE)

- $\hfill\square$ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - ___ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)

Equipment varies by model. Perform only those operations that apply to your vehicle.

56,250 MILES OR 45 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 60,000 Miles or 48 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

3 ⋗ ____ Z -Z ⋗ Z 0 S 0 т C

60,000 MILES OR 48 MONTHS

SCHEDULE 1 AND 2

OPTIONAL PREMIUM UPGRADE

- Replace engine oil and filter Replace brake fluid Lubricate all locks/hinges □ Replace engine air filter □ Replace spark plugs (G37 Coupe IPL) Replace differential oil □ Replace in-cabin microfilter □ Rotate tires (refer to page 9 for exceptions) □ Inspect the following: Automatic transmission fluid ^{1,3} Front suspension ball joints Axle & suspension parts Fuel lines/connections Brake lines & cables ____ Fuel tank vapor vent system hoses Brake calipers, pads, rotors Propeller shaft (4WD/AWD/RWD) Brake light and cruise control Steering gear and linkage All lights switches² Steering linkage ball joints Manual transmission oil¹ Differential oil 1 Transfer case oil (4WD/AWD)¹ Drive shaft boots (4WD/AWD) Engine drive belts
 - Exhaust system
- Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

□ For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

Premium	Upgrade	adds	the	following	services	tc
Schedule	1 & 2:					

- □ Replace automatic transmission fluid ³
- Replace engine drive belts
- □ Replace manual transmission oil
- Replace radiator cap
- □ Replace transfer case oil (4WD/AWD)
- □ Replace wiper blades
- □ Inspect the following:
- Headlights/adjust if necessary

63,750 MILES OR 51 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 67,500 Miles or 54 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

67,500 MILES OR 54 MONTHS

SCHEDULE 1 (MORE SEVERE)

- $\hfill\square$ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - ___ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

Replace engine oil and filter
 Rotate tires (refer to page 9 for exceptions)

Equipment varies by model. Perform only those operations that apply to your vehicle.

71,250 MILES OR 57 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 75,000 Miles or 60 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

75,000 MILES OR 60 MONTHS

SCHEDULE 1 (MORE SEVERE)

- □ Replace engine oil and filter
- Replace brake fluid
- Replace in-cabin microfilter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ____ Automatic transmission fluid ²
 - ___ Axle & suspension parts
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches ¹
 - __ Differential oil
 - __ Drive shaft boots (4WD/AWD)
 - ___ Engine drive belts
 - __ Exhaust system
 - ___ Front suspension ball joints
 - ___ Manual transmission oil
 - Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - __ Steering linkage ball joints
 - ___ Transfer case oil (4WD/AWD)

SCHEDULE 2 (LESS SEVERE)

- □ Replace engine oil and filter
- □ Replace in-cabin microfilter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Automatic transmission fluid ²
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches ¹
 - __ Differential oil
 - __ Drive shaft boots (4WD/AWD)
 - __ Engine drive belts
 - ___ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Transfer case oil (4WD/AWD)

3

⋗

- ¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ² Except models with 7-speed automatic transmission. Equipment varies by model. Perform only those operations that apply to your vehicle.
- □ For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

78,750 MILES OR 63 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 82,500 Miles or 66 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

82,500 MILES OR 66 MONTHS

SCHEDULE 1 (MORE SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - __ Drive shaft boots (4WD/AWD)
 - __ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

Replace engine oil and filter
 Rotate tires (refer to page 9 for exceptions)

Equipment varies by model. Perform only those operations that apply to your vehicle.

86,250 MILES OR 69 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 90,000 Miles or 72 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

3 ⋗ Z -Z ⋗ Ζ 0 S 0 т C

90,000 MILES OR 72 MONTHS

SCHEDULE 1 AND 2

- Replace engine oil and filter
- Replace brake fluid
- Replace engine air filter
- □ Replace in-cabin microfilter
- □ Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
- ____ Automatic transmission fluid ^{1,3} ____ Front suspension ball joints
- ___ Axle & suspension parts
- ___ Brake lines & cables
- ___ Brake calipers, pads, rotors
- Brake light and cruise control switches²
- __ Differential oil 1
- __ Drive shaft boots (4WD/AWD)
- ___ Engine drive belts
- _ Exhaust system

- _____ Front suspension ball joints _____ Fuel lines/connections
- __ Fuel tank vapor vent system hoses __ Propeller shaft (4WD/AWD/RWD)
- ____ Propeller shaft (4WD/AWD/RWD)
- ___ Steering gear and linkage
- ___ Steering linkage ball joints
- ____Manual transmission oil 1
- ___ Transfer case oil (4WD/AWD) 1

OPTIONAL PREMIUM UPGRADE

Premium Upgrade adds the following services to Schedule 1 & 2:

- Lubricate all locks/hinges
- □ Replace automatic transmission fluid ³
- Replace differential oil
- Replace engine drive belts
- Replace manual transmission oil
- Replace radiator cap
- □ Replace transfer case oil (4WD/AWD)
- Replace wiper blades
- □ Inspect the following:
- __ All lights __ Headlights/adjust if necessary

- Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

□ For the ultimate in preventative maintenance, ask your Service Consultant for a complimentary Multi-Point Inspection every time you visit your participating Infiniti dealer. See page 12 and 13 for more information on Multi-Point Inspections.

93,750 MILES OR 75 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 97,500 Miles or 78 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

97,500 MILES OR 78 MONTHS

SCHEDULE 1 (MORE SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - __ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

- □ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)

Equipment varies by model. Perform only those operations that apply to your vehicle.

101,250 MILES OR 81 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 105,000 Miles or 84 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

105,000 MILES OR 84 MONTHS

SCHEDULE 1 (MORE SEVERE)

- Replace engine oil and filter
- Replace brake fluid
- □ Replace in-cabin microfilter
- □ Replace engine coolant³
- □ Replace spark plugs
- □ Rotate tires (refer to page 9 for exceptions)
- Inspect the following:
 - ____ Automatic transmission fluid ²
 - ___ Axle & suspension parts
 - __ Brake lines & cables
 - ___ Brake calipers, pads, rotors
 - ___ Brake light & cruise control switches ¹
 - __ Differential oil
 - ___ Drive shaft boots (4WD/AWD)
 - _ Engine drive belts

- ___ Exhaust system
 - __ Front suspension ball joints
 - ___ Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints
 - ___ Transfer case oil (4WD/AWD)

SCHEDULE 2 (LESS SEVERE)

- Replace engine oil and filter
 Replace in-cabin microfilter
 Replace engine coolant³
 Replace spark plugs
 Rotate tires (refer to page 9 for exceptions)
 Inspect the following:

 Automatic transmission fluid ²
 Brake lines & cables
 Brake calipers, pads, rotors
 Brake light & cruise control switches ¹
 Differential oil
 Drive shaft boots (4WD/AWD)
 Engine drive belts
 Manual transmission oil
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Transfer case oil (4WD/AWD)
- ¹ Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ² Except models with 7-speed automatic transmission.
- ³ Subsequent replacement of Genuine Nissan Long Life Antifreeze/Coolant (Blue) should occur every 75,000 miles (120,000km) or 5 years whichever comes first.

Equipment varies by model. Perform only those operations that apply to your vehicle.

108,750 MILES OR 87 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 112,500 Miles or 90 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

112,500 MILES OR 90 MONTHS

SCHEDULE 1 (MORE SEVERE)

- $\hfill\square$ Replace engine oil and filter
- Rotate tires (refer to page 9 for exceptions)
- □ Inspect the following:
 - ___ Axle & suspension parts
 - ___ Brake calipers, pads, rotors
 - ___ Drive shaft boots (4WD/AWD)
 - ___ Exhaust system
 - ___ Front suspension ball joints
 - ___ Propeller shaft (4WD/AWD/RWD)
 - ___ Steering gear and linkage
 - ___ Steering linkage ball joints

SCHEDULE 2 (LESS SEVERE)

Replace engine oil and filter
 Rotate tires (refer to page 9 for exceptions)

Equipment varies by model. Perform only those operations that apply to your vehicle.

116,250 MILES OR 93 MONTHS

SCHEDULE 1 (MORE SEVERE)

□ Replace engine oil and filter

SCHEDULE 2 (LESS SEVERE)

Next scheduled maintenance at 120,000 Miles or 96 Months

Equipment varies by model. Perform only those operations that apply to your vehicle.

120,000 MILES OR 96 MONTHS

SCHEDULE 1 AND 2 OPTIONAL PREMIUM UPGRADE □ Replace engine oil and filter Premium Upgrade adds the following services to Schedule 1 & 2: Replace brake fluid □ Replace engine air filter Lubricate all locks/hinges □ Replace spark plugs (G37 Coupe IPL) □ Replace automatic transmission fluid ³ □ Replace in-cabin microfilter Replace differential oil Replace engine drive belts Rotate tires (refer to page 9 for exceptions) □ Replace manual transmission oil □ Inspect the following: Replace radiator cap Automatic transmission fluid ^{1,3} Front suspension ball joints □ Replace transfer case oil (4WD/AWD) Axle & suspension parts Fuel lines/connections □ Replace wiper blades Brake lines & cables ____ Fuel tank vapor vent system hoses Propeller shaft (4WD/AWD/RWD) □ Inspect the following: Brake calipers, pads, rotors Brake light and cruise control ___ Steering gear and linkage All lights __ Steering linkage ball joints switches² Headlights/adjust if necessary Manual transmission oil ¹ Differential oil 1 Transfer case oil (4WD/AWD)¹ Drive shaft boots (4WD/AWD) Engine drive belts Exhaust system

- Replace (not just inspect) oil/fluid if towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads.
- ² Inspect the clearance between the brake pedal and the switches (G37 Sedan, G37 Coupe and G37 Convertible).
- ³ Except models with 7-speed automatic transmission.

Equipment varies by model. Perform only those operations that apply to your vehicle.

3,750 Miles or 3 Months	7,500 Miles or 6 Months	11,250 Miles or 9 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
15,000 Miles or 12 Months	18,750 Miles or 15 Months	22,500 Miles or 18 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
26,250 Miles or 21 Months	30,000 Miles or 24 Months	33,750 Miles or 27 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:

37,500 Miles or 30 Months	41,250 Miles or 33 Months	45,000 Miles or 36 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
48,750 Miles or 39 Months	52,500 Miles or 42 Months	56,250 Miles or 45 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
60,000 Miles or 48 Months	63,750 Miles or 51 Months	67,500 Miles or 54 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:

71,250 Miles or 57 Months	75,000 Miles or 60 Months	78,750 Miles or 63 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
82,500 Miles or 66 Months	86,250 Miles or 69 Months	90,000 Miles or 72 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
93,750 Miles or 75 Months	97,500 Miles or 78 Months	101,250 Miles or 81 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:

105,000 Miles or 84 Months	108,750 Miles or 87 Months	112,500 Miles or 90 Months
Dealer Name:	Dealer Name:	Dealer Name:
Date:	Date:	Date:
Mileage:	Mileage:	Mileage:
Dealer	Dealer	Dealer
Stamp:	Stamp:	Stamp:
116,250 Miles or 93 Months	120,000 Miles or 96 Months	
116,250 Miles or 93 Months Dealer Name:	120,000 Miles or 96 Months Dealer Name:	
Dealer Name:	Dealer Name:	
Dealer Name: Date:	Dealer Name: Date:	
Dealer Name:	Dealer Name:	
Dealer Name: Date: Mileage:	Dealer Name: Date: Mileage:	



