


# 2011 Infiniti M

Quick Reference Guide



INFINITI.



- 01** ADAPTIVE FRONT LIGHTING SYSTEM (AFS) SWITCH\*
- 02** INSTRUMENT BRIGHTNESS CONTROL SWITCH
- 03** WINDSHIELD WIPER AND WASHER SWITCH
- 04** HEADLIGHT AND TURN SIGNAL SWITCH
- 05** STEERING WHEEL SWITCHES FOR AUDIO / BLUETOOTH®
- 06** CRUISE CONTROL
- 07** BLIND SPOT INTERVENTION™ (BSI) SWITCH
- 08** VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH
- 09** BLIND SPOT WARNING (BSW) SWITCH
- 10** TILT / TELESCOPIC STEERING WHEEL SWITCH
- 11** TRUNK LID RELEASE SWITCH
- 12** INTELLIGENT BRAKE ASSIST (IBA) SWITCH\*
- 13** REAR SUNSHADE SWITCH\*
- 14** HEATED STEERING WHEEL SWITCH\*
- 15** HOOD RELEASE
- 16** CONTROL PANEL DISPLAY SCREEN
- 17** CLIMATE CONTROL SYSTEM
- 18** AUDIO SYSTEM
- 19** DRIVER'S CLIMATE CONTROLLED SEAT SWITCH
- 20** INFINITI DRIVE MODE SELECTOR

\*See your Owner's Manual for more information.

## new system features

Forest Air™ System (if so equipped) . . . . .	2
Blind Spot Warning (BSW) and Blind Spot Intervention™ (BSI) (if so equipped) . . . . .	2
ECO Pedal System (if so equipped) . . . . .	2

## first drive features

INFINITI Intelligent Key™ System . . . . .	3
Seat Adjustments . . . . .	3
Outside Mirror Control Switch . . . . .	3
Starting the Engine . . . . .	4
Headlight Control Switch . . . . .	4
Windshield Wiper Switch . . . . .	4
Automatic Climate Controls . . . . .	5
FM/AM/XM® Radio with CD Player . . . . .	5
Parking Brake . . . . .	6
Trunk Lid Release . . . . .	6
Fuel-Filler Door . . . . .	7

## system guide

Cruise Control . . . . .	8
Bluetooth® Hands-free Phone System . . . . .	8
Navigation System (if so equipped) . . . . .	8
HomeLink® Universal Transceiver . . . . .	8



- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the “**Safety — Seats, seat belts and supplemental restraint system (section 1)**” of your Owner’s Manual.



Additional Information about your vehicle is also available in your Owner’s Manual, Navigation System Owner’s Manual and at [www.InfinityUSA.com](http://www.InfinityUSA.com).

This easy-to-use Quick Reference Guide is intended to help you more fully appreciate some of the unique features and functions of your new vehicle. However, it is not intended to replace your Owner’s Manual. The Owner’s Manual contains more detailed information to help you better understand the important safety warnings, features, operation and maintenance of your vehicle. All information, specifications, photographs and illustrations in this publication are those in effect at the time of printing. INFINITI reserves the right to change specifications or design without notice and without obligation.

# new system features

## Forest Air™ System (if so equipped)

- This system helps keep the air inside your vehicle clean using:
  - Plasmacluster™ ion control and grape polyphenol filter.
  - An automatic air intake system with an outside odor and exhaust gas detecting sensor.
  - Automatic ventilation with an inside air quality sensor.
- The Forest Air™ system also makes the inside of your vehicle more comfortable, using the Breeze Mode feature.



For more information, refer to the **"Monitor, climate, audio, phone and voice recognition systems (section 4)"** of your Owner's Manual.

## Blind Spot Warning (BSW) and Blind Spot Intervention™ (BSI) (if so equipped)

- The Blind Spot Warning (BSW) system alerts the driver when another vehicle moves into the vehicle's blind spot area.
- The Blind Spot Intervention™ (BSI) system can assist the driver in returning the vehicle to the center of the traveling lane by applying individual brake pressure to the left or right wheels for a short period of time.



For more information, refer to the **"Starting and driving (section 5)"** of your Owner's Manual.

## ECO Pedal System (if so equipped)

- With the Infiniti Drive Mode Selector switch **01** in the ECO Mode, the ECO pedal system assists the driver in improving fuel economy.
- The ECO pedal system applies force to make the accelerator pedal heavier depending on the accelerator pedal operation.



For more information, refer to the **"Starting and driving (section 5)"** of your Owner's Manual.

# first drive features

## INFINITI Intelligent Key™ System

The INFINITI Intelligent Key™ system allows you to lock or unlock your vehicle, open your trunk and start the engine.

- To lock or unlock the driver's or front passenger's door, push the door handle request switch **01** once.
- Push the door handle request switch **01** within 1 minute of unlocking the door and all other doors will unlock.

**NOTE:** It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.



## Seat Adjustments

- Push the control switch **01** forward or backward to slide the seat forward or backward.
- Push the switch **02** forward or backward to recline the seatback.



### SEAT LIFTER


- To raise or lower the front portion or height of the seat, push the front or rear end of the switch **01** up or down.

For more information, refer to the "Safety — seats, seat belts and supplemental restraint system (section 1)" section of your Owner's Manual.



## Outside Mirror Control Switch

- Move the control switch **01** right or left to select the right or left side mirror.
- Adjust each mirror to the desired position using the switch **02**.
- Push the switch **03** to the  position to fold the outside rearview mirrors and push the switch **03** to the  position to unfold the outside rearview mirrors.



For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.

# first drive features

## Starting The Engine

- Depress the brake pedal.
- Press the ignition switch **START/STOP** button to start the engine.

NOTE: It is important to make sure the INFINITI Intelligent Key™ is with you (that is, in your pocket or purse).



### TURNING THE ENGINE OFF

- Move the shift lever to the P (PARK) position and apply the parking brake.
- Press the ignition switch **START/STOP** button to turn the engine off.




For more information, refer to the "**Starting and driving (section 5)**" of your Owner's Manual.

## Headlight Control Switch

- Turn the headlight control switch **01** to the  position to turn on the front parking, side marker, tail and license plate lights.
- Turn the switch **01** to the  position to turn on the headlights.

For more information, refer to the "**Instruments and controls (section 2)**" of your Owner's Manual.




## Windshield Wiper Switch

- Move the lever to the following positions to operate the windshield wipers:

- 01** Mist (**MIST**) - One sweep operation of the wipers.
- 02** Auto (**AUTO**) - Operates the rain-sensing auto wiper system.
- 03** Low (**LO**) - Wipers operate at a continuous low-speed.
- 04** High (**HI**) - Wipers operate at a continuous high-speed.

- When the windshield wipers are operated continuously, your headlights will turn on automatically.



For more information, refer to the "**Instruments and controls (section 2)**" of your Owner's Manual.

## Automatic Climate Controls




### 01 AUTO BUTTON

Press the **AUTO** button to turn the system on and the fan speed, air flow distribution and temperature will be automatically maintained.

### 02 TEMPERATURE CONTROL BUTTONS

Press the driver's side temperature control buttons down for cold air or up for hot air.

### 03 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

Press the defroster control button  to turn the system on or off.

### 04 DEFROSTING REAR WINDOW AND OUTSIDE MIRRORS

Push the rear window defroster switch  **REAR** to turn the system on or off.

For more information, refer to the **"Monitor, climate, audio, phone and voice recognition systems (section 4)"** of your Owner's Manual.

## FM/AM/XM<sup>®</sup>\* Radio With CD Player



### 01 ON/OFF VOLUME CONTROL DIAL

Press the **VOL** button to turn the system on or off. Turn the dial right or left to increase or decrease the volume.

### 02 TUNE/FOLDER/AUDIO CONTROL DIAL

To manually tune the radio, turn the **TUNE/FOLDER** dial left or right.

\*XM<sup>®</sup> Satellite Radio is only available on vehicles equipped with optional XM<sup>®</sup> satellite subscription service.



For more information, refer to the **"Monitor, climate, audio, phone and voice recognition systems (section 4)"** of your Owner's Manual.

# first drive features

## Parking Brake


- To apply, firmly depress the parking brake pedal **01**.
- To release, firmly press the foot brake **02**, then press the parking brake pedal **01** and the parking brake will release.


For more information, refer to the “Starting and driving (section 5)” of your Owner’s Manual.



## Trunk Lid Release


Use one of the following methods to open the trunk:

- Push the trunk open request switch **01** under the trunk handle and lift up on the trunk lid.
- Press the trunk button  on the INFINITI Intelligent Key™ for more than one second.



- From inside the vehicle, push the trunk lid release switch **01**.

For more information, refer to the “Pre-driving checks and adjustments (section 3)” of your Owner’s Manual.





## Fuel-Filler Door

The fuel-filler door is located on the right, rear side of the vehicle.

- When the doors of the vehicle are locked or unlocked, the fuel-filler door is automatically locked or unlocked at the same time.
- To open the door, once unlocked, push the upper left side of the door.
- If the **SERVICE ENGINE SOON** light illuminates because the fuel cap is loose or missing, tighten or install the cap. The **SERVICE ENGINE SOON** light should turn off after a few driving trips.



For more information, refer to the **"Pre-driving checks and adjustments (section 3)"** of your Owner's Manual.

# system guide

## Cruise Control

- The cruise control system enables you to set a constant cruising speed.
- The system will automatically maintain the set speed until you decelerate, accelerate, cancel or turn off the system.

For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.



## Bluetooth® Hands-free Phone System

- With an overhead microphone and sound transmitted through the audio system speakers, the Bluetooth® Hands-free Phone System utilizes Bluetooth® wireless technology and voice recognition to provide hands-free cellular phone communication.

For more information, refer to the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual or please visit [www.InfinitiUSA.com/bluetooth](http://www.InfinitiUSA.com/bluetooth).



## Navigation System (if so equipped)




- Your Navigation system can calculate a route from the current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- Your vehicle’s position is constantly tracked. If you have deviated from the original route, it will recalculate the route from your current location.
- The Navigation system can also provide you with important data, such as; distance to empty, your tire rotation schedule and other maintenance interval reminders.

For more information, please refer to your Navigation System Owner’s Manual.

## HomeLink® Universal Transceiver

The HomeLink® system can learn and consolidate the functions of up to three different hand-held transmitters, operating items such as; garage doors, property gates, outdoor and indoor lights or alarm systems.



For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual, the HomeLink® website [www.homelink.com](http://www.homelink.com) or call 1-800-355-3515.





INFINITI.

All illustrations, photographs and specifications in this guide are based on the latest product information; some vehicle parts cannot be shown in certain photographs. Some vehicles are shown with optional equipment. See actual vehicles for complete accuracy. Infiniti Division of Nissan North America, Inc. reserves the right to make changes at any time, without notice, in prices, colors, materials, equipment, specifications and models, and to discontinue models or equipment. Availability and delivery time for particular models and equipment combinations may vary. For information on availability, additional options or accessories, contact your Infiniti dealer. All specifications, options and accessories shown in this guide apply to the 49 continental states. Specifications, options and accessories may differ in Hawaii, U.S. territories and other countries. INFINITI, the Infiniti logo and INFINITI model names are Nissan trademarks.